


CM Breakdown and Part list
Schéma et le liste de pièce

Gas Engine / *Moteur à essence*
(GE5.5, GE6.5, GE9.0, GE11, GE13)



Tel.: 1-877-405-2626, Fax: 1-877-405-8686
Web site: www.cm-equip.com
E-mail: info@cm-equip.com

1a. Crankcase for 5.5, 6.5 HP / Carter de moteur pour 5.5, 6.5 cv




5.5 & 6.5 HP

No.	Pièce/parts
GE101	Crankcase
GE102	Oil seal
GE103	Radial ball bearing
GE104	Governor arm shaft
GE105	Lock nip
GE106	Plain washer
GE107	Drain plug bolt
GE108	Drain plug washer
GE109	governor kit
GE109a	Governor weight
GE109b	Governor weight pin
GE109c	Governor gear
GE110	Governor shaft
GE111	Governor shaft clip
GE112	Governor
GE113	Plain washer $\Phi 6$
GE114	Radial ball bearing
GE115	Oil seal
GE116	String ring
GE117	Dip clip
GE118	Flange bolt M6x10

1b. Crankcase for 9.0, 11,13 HP / Carter de moteur pour 9.0, 11,13 cv


8,9,11,&13HP




No.	Pièce/parts
GE101	Crankcase
GE102	Oil seal
GE103	Radial ball bearing
GE104	Governor arm shaft
GE105	Lock nip
GE106	Plain washer
GE107	Drain plug bolt
GE108	Drain plug washer
GE109	governor kit
GE109a	Governor weight
GE109b	Governor weight pin
GE109c	Governor gear
GE110	Governor shaft
GE111	Governor shaft clip
GE112	Governor
GE113	Plain washer Φ6
GE114	Radial ball bearing
GE115	Oil seal
GE116	String ring
GE117	Dip clip
GE118	Flange bolt M6x10

2. Crankcase Cover Assy / Couvercle pour carter

5.5 & 6.5HP




8, 9, 11 & 13HP



No.	Pièce/parts
GE201	Crankcase cover
GE202	Oil seal
GE203	Radial ball bearing
GE204	Oil filler cap
GE205	seal
GE206	Dowel pin
GE207	Crankcase gasket
GE208	Flange bolt
GE209	Radial ball bearing


3. Crankshaft Piston & Connecting Rod / *Piston de vilebrequin et bielle*



No.	Pièce/parts
GE301	Crankshaft
GE302	Timing driving gear
GE303	Drive gear
GE304	Woodruffkey
GE305	Rod assy connecting
GE306	Piston
GE307	Piston pin
GE308	Piston pin clip
GE309	Piston ring set
GE310	Balance shaft

4a. Cylinder Head & Cylinder Cover for 5.5, 6.5 HP / Couvercle de culasse de 5.5, 6.5 cv


5.5 & 6.5HP



No.	Pièce/parts
GE401	Cylinder head comp
GE401a	Cylinder head
GE401b	In-valve guide
GE401c	Ex-valve guide
GE401d	Valve guide clip
GE401e	Intake valve seat
GE401f	Exhaust valve seat
GE402	Stud bolt
GE403	Dowel pin
GE404	Spark plug
GE405	Gasket, Cylinder head
GE406	Head cover comp
GE407	Gasket, cylinder cover
GE408	Breather tube assy
GE409	Head cover bolt
GE410	Lead wind cover
GE411	bolt
GE412	Stud bolt
GE413	Flange bolt M6x12
GE414	Stud bolt M8x24
GE415	Stud bolt

4b. Cylinder Head & Cylinder Cover for 9.0, 11,13HP / *Couvercle de culasse*


8, 9, 11 & 13 HP



No.	Pièce/parts
GE401	Cylinder head comp
GE401a	Cylinder head
GE401b	In-valve guide
GE401c	Ex-valve guide
GE401d	Valve guide clip
GE401e	Intake valve seat
GE401f	Exhaust valve seat
GE402	Stud bolt
GE403	Dowel pin
GE404	Spark plug
GE405	Gasket, Cylinder head
GE406	Head cover comp
GE407	Gasket, cylinder cover
GE408	Breather tube assy
GE409	Head cover bolt
GE410	Lead wind cover
GE411	bolt
GE412	Stud bolt
GE413	Flange bolt M6x12
GE414	Stud bolt M8x24
GE415	Stud bolt


5. Combination of Camshaft & Valve Rocker for 5.5-13 HP

Arbre à cames et culbuteur de soupape pour 5.5-13cv




No.	Pièce/parts
GE501	camshaft assy
GE502	valve teppet
GE503	push rod
GE504	push rod guide plate
GE505	valve rocker
GE506	rocker pivot pin
GE507	pivot bolt
GE508	pivot adjusting nut
GE509	in-take valve
GE510	exhaust valve
GE511	valve spring
GE512	in-valve spring seat
GE513	ex-valve spring seat
GE514	valve rotator
GE515	spring retainer exhaust valve
GE516	guide oil seal

6. Recoil Starter for 5.5-13 HP/ Démarreur à rappel




No.	Pièce/parts
GE601	Fan hood
GE602	Flange bolt M6x12
GE603	Starter rolls assy
GE604	Flange bolt
GE605	Shroud comp
GE606	Screw M6x12
GE607	Swallow clip
GE608	Twin clip
GE601a	Fan hood (for electrical start)
GE605a	Shroud comp (for electrical start)

7. Carburetor Assy / Carburateur




No.	Pièce/parts
GE701	Carburetor for engine
GE702	Carburetor for generator
GE703	Air cleaner gasket
GE704	Carburetor gasket
GE705	Connecting block for engine
GE705a	Connecting block for generator
GE706	Inlet gasket
GE707	Check valve assy for generator
GE708	Manual choke assy for generator

8. Air Filter / Épurateur d'air



No.	Pièce/parts
GE801	Air filter for engine
GE802	Air filter for generator
GE801a	Air filter elbow comp
GE801b	Air filter collar A
GE801c	Air filter collar B
GE801d	Elbow packing
GE801e	Air filter base
GE801f	Bolt M4x14
GE801g	Cover nut M6
GE801h	Air filter cover
GE801j	Air filter element
GE802a	Air filter elbow comp
GE802b	Air filter element
GE802c	Air filter cover
GE803	Nut M6



9. Regulating Control System / *Système de commande de régulation*




No.	Pièce/parts
GE901	Speed control assy for engines
GE902	Speed control assy for generators
GE903	Flange bolt M6X12
GE904	Governor rod
GE905	Throttle return spring
GE906	Governor spring
GE907	Regulating arm
GE908	Governor arm bolt M6X21
GE909	Bolt M6

10. Muffler / Silencieux

No.	Pièce/parts
GE1001	Muffler assy
GE1002	Muffler gasket
GE1003	Bolt M8
GE1004	Exhaust valve tube
GE1005	Mufflet gasket
GE1006	Bolt M8




11. Fuel Tank / Réservoir de carburant



No.	Pièce/parts
GE1101	Fuel tank assy
GE1102	Gasket
GE1103	Fuel tank joint
GE1104	Fuel tube
GE1105	Supporter rubber pipe
GE1106	Tube clip
GE1107	Bolt M6/M8
GE1108	Screw M6x22/M8x22
GE1109	Oil tube clamp

12. Flywheel / Volant



No.	Pièce/parts
GE1201	Flywheel comp
GE1202	Flywheel comp
GE1203	Cooling fan
GE1204	Starter pulley
GE1205	Flywheel special nut M14X1.5 / M16X1.5
GE1206	Ignition coil
GE1207	Flange bolt M6X28
GE1208	Oil sensor
GE1209	Flange bolt M6X14
GE1210	Special nut M10
GE1211	Engine stop switch assy
GE1212	Diode
GE1213	Charging coil
GE1214	Starting motor assy
GE1215	Control assy
GE1216	Starting motor dowel pin