

COMMON REPLACEMENT PARTS LIST

MODEL: IDH 1000 TRAILER

FUEL TYPE: OIL/DIESEL W/IDH500QR (INSIDE) WITH BEACON LIGHT

PART#	DESCRIPTION	QTY
100019	FUEL LINE HOSE	1
11204	LEVER LATCH C2-32-15 (SHORT)	1
11205	LEVER LATCH C2-33-15 (LONG)	1
11304	FUEL FILTER BRACKET ASSY	1
11352	GENERATOR CONTAINMENT TANK	1
11502	FUEL HEATER TANK GUAGE	1
11503	FUEL GENERATOR TANK GUAGE	1
11504	DOOR LIMIT SWITCH SNAP	1
11505	DOOR LIMIT EXTENSIOIN SNAP	1
11510	LIGHTED PUSH BUTTON ZB5AH033	1
11511	SWITCH LIGHTED (ZBVG3)	1
11514	MOUNTING COLLAR ZB5AZ101	1
11515	LED LIGHT, GRO BZ301-5	1
11516	OUTSIDE PLUG IN (PWR INLET-HUBBLE 5278C)	1
11517	OUTSIDE PLUG IN COVER (PWR INLET COVER- HBWP1)	1
11520	OUTSIDE PLUG OUT SINGLE 15AMP	1
11522	TIMER RELAY (RE17RMMW)	1
11523	SINGLE CONTACT BLOCK (ZBE5013)	1

11527	RECEPTACLE, WHITE 125VAC 14A	1
11536	GREEN PUSH BUTTON (ZB5 AA3)	1
48126	FUEL CAP (STANT 10625)	1
48128F	SUCTION TUBE ASSY 12"	1
48165	THERMOSTAT RECEPTACLE	1
48807	6" X 36" FLUE PIPE	1
48808	6" VENT CAP	1
50144	PRIMARY CONTROLLER	1
100047	COMPARTMENT DOOR "HOLD OPEN" LATCHES	1
70026	VENT GRILLS (LOUVERS)	1
11535	WHITE PLUG COVER (GFCI - IPEWGF1510)	1
11501	FUEL LEVEL SENDER (VDO 918226-002) WHITE FLOAT	1
11506	GENERATOR FUEL SENDER (VDO 226-007)	1
B30250	160 PSI FUEL PRESSURE GUAGE	1
48132	FUEL FILTER ASSY (1A-25)	1
48164	FUEL FILTER (1A-30)	12
70092	SPILTTER BLOCK	1
11509	20 AMP CIRCUIT BREAKER	1
11521	15 AMP CIRCUIT BREAKER	1
GM96383	BATTERY CHARGER (DO NOT SELL OR CARRY THIS)	
11507	SWITCH;TATTLE (518E-12)	1
11508	PRESSURE SWITCH GAGE (20P-100)	1
1150	FUEL LEVEL SENDER BLACK FLOAT (NEW)	1
1151	FUEL GAUGE (WHITE/CHROME) (NEW)	1

11561	LED MULTIMETER MURATA	1
60164	PLASTIC PLUG COVER	1
48112D	PROBE HIGH LIMIT	1
10116	100 AMP CIRCUIT BREAKER	1
10509	80 AMP CIRCUIT BREAKER	1
100094	FUEL CAP 3"	1
100083	1 AMP FUSE	1
11540	10 AMP FUSE	1
50214	FUSE HOLDER	1
11569	SMART RELAY W/CLOCK	1
101031B	BEACON LIGHT	1
P11453	BATTERY ASSEMBLY	1
B50289QR	IDF500 BURNER (CF800)	1